

AKRPlayer
User Manual


1. PC requirement and OS

Item	Min. Requirements	Recommended Specifications
CPU	Pentium III 800	Above Pentium IV 2.0G
Main Memory	256 MB	Above 256MB
O/S*	Windows 2000	Window 2000 or XP
Web Browser	I.E 5.0	Above I.E 5.0
Resolution	1,024 X 768	1,152 X 864
Network	100Base-T Ethernet	100Base-T Ethernet

2. Operating System


- ✓ Windows 2000 Professional (Korean OS, English OS, Japanese OS)
- ✓ Windows XP Professional / Windows XP Home Edition(Korean OS, English OS, Japanese OS)
- ✓ Windows 2000 Server (Korean OS, English OS, Japanese OS)

3. Set up(Execute Setup_0303)




Pic. 3—1 Select language

Click NEXT button..




Pic. 3—2 Set up the program


Click 'Next' to start installation.



Pic. 3—3 License




Pic. 3—4 Setup Status



Pic. 3—5 Setup Complete

Upon completion of installation, click 'Finish' Button.

4.1 AKR Player Screen



Pic. 4—1 Player Screen



Open file or directory



File conversion from ST4 to AVI format.



- ① Move to previous frame
- ② Rewind
- ③ Play/Pause
- ④ Stop
- ⑤ Fast Forward
- ⑥ Move to Next frame

SEARCH LIST

Display search result.

LIST VIEW

Display files users open manually.

↑ BACKUP

ST4 files backup button.



Slide bar for displaying recorded files.



Mute, Sound control bar.


START 2007-05-21 10:18:19 END 2007-05-21 10:20:00
 CURRENT 2007-05-21 10:18:24 SIZE 14731 KB

Displaying current status of Player
 (Start date/time, End date/time , Current date/time, File Size)

Table 4-1 Definition of AKR Player Menu


4.2 Open (File / Directory)

4.2-1 File open




Pic. 4.2-1 File open

4.2-2 Directory open




Pic. 4.2-2 Directory open

4.2-3 Load ST4 Files




Pic. 4.2-3 Load ST4 Files

4.2-4 SDR File Play & Play Size Control




Pic. 4.2-4 SDR File Play

4.3 AVI Convert




Pic. 4.3-1 Select File to convert to 'AVI' format



Pic. 4.3-2 Save as AVI file name


4.4 Backup



Pic. 4.4-1 'Backup' Button

- ① Click 'Backup' button to open 'backup tool' as shown in [Pic. 4.7-1].


4.4-1 Source Files



Pic. 4.4-2 Source Files

- ② Source Files Directory: Shows the folder where the files are held.
- ③ Source Files Window: Shows the files that are currently in the list view.
- ④ Move all files in 'Source Files Window' to 'Target Files Window'.
- ⑤ Move highlighted files in 'Source Files Window' to the 'Target Files Window'.
- ⑥ Cancel desired files in 'Target Files Window'.
- ⑦ Cancel all files in 'Target Files Window'.


4.4-2 Target Files



Pic. 4.4-3 Target Files

- ⑧ Target Files Directory: Select the folder where you to backup.
- ⑨ Prefix: You can add prefix to original file name.
- ⑩ Target Files Window: The files you want to backup are displayed.
- ⑪ Click 'Backup' button to backup the listed files.

4.4-3 Backup Result



Pic. 4.4-4 Backup Result

- ⑫ Backup result is shown on 'Backup Result' window.
- ⑬ Click 'Close' button to close 'Backup' window.